

ASSEMBLY INSTRUCTIONS FOR YOUR APOLLO FLOOR LAMP

SAFETY INSTRUCTIONS:

- *These instructions are provided for your safety. It is important that they are read completely before beginning installation.
- * This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, contact a qualified electrician.
- * Do NOT alter the plug.
- * Switch power off and remove plug from the wall outlet before replacing the bulb.

ASSEMBLY INSTRUCTIONS:

1. Unpack all parts and place them on a level surface.
2. Thread column (B) onto base (A). Turn until hand tight.
3. Thread column (C) onto column (B). Turn until hand tight.
4. Lift shade to column and align hole in shade bracket (D) with hole in the top of column (C).
5. Slide screw (F) through washer (E) and shade bracket (D). Use wrench (G) to secure screw (F) into column (C).
6. Remove shade lens (H) by removing screws (I).
7. Insert one 150W Max. Type A, medium base bulb into the socket.
8. Place lens (H) back onto the shade and use screws (I) to secure it into place.
9. Insert plug (J) into wall outlet.
10. Use switch (K) to control power to the lamp.

** To clean, wipe with a soft cloth only. Do not use chemical or abrasive cleaners as they can damage the finish of the lamp. **

